

MANUAL

Please read the manual very carefully before using Keep the printed instructions for further reference and read it carefully before use!



NAME OF MAJOR COMPONENTS

IMPORTANT! Read carefully and keep for future reference

WARNING: To reduce the risk of injury, user must read instruction manual.

WARNING: Prolonged Exposure to UV Rays, Rain and the Elements May

Damage the Enclosure Materials. Store Indoors When Not in Use.

WARNING: Risk of Fire, No User Serviceable Parts.

Charge: 0~40°C

Operation: -5~40°C

Model number: 73T

- —"WARNING! As with any mechanical component, a vehicle is subject to high stresses and wear. The various materials and components may react differently to wear or fatigue. If the expected service life for a component has been exceeded, it may break suddenly, therefore risking causing injuries to the user. Cracks, scratches and discoloration in the areas subject to high stresses indicate that the component has exceeded its service life and should be replaced."
- —WARNING Keep plastic covering away from children to avoid suffocation.
- —WARNING: the brake may become hot in use. Do not touch after use.
- —WARNING!: Never use the product out of the spaces authorized by the regulations



INSTRUCTION

- 1. This product just for one adult only, not possible for two or more persons
- 2. Please must be use helmet or other safety device during riding
- 3.Please don51 ride it on unsafe place and don51 break traffic regulations
- 4. Please have a try on an empty place before riding on the road
- 5.Don* t make dangerous action or riding by single hand during riding
- 6.Please try to avoid obstacle with height more than 3cm, otherwise, it is easily fall down, your body and the scooter shall be hurt
- 7.Max speed of the vehicle is 30km/h
- 8. Please don't ride it when the temperature under-5 degree
- 9.Please must be reduce the speed or get offthe scooter to pass by rugged road
- 10.Don, t ride it on the ground with oil or ice
- 11. Adjust the height of the scooter according to your height
- 12.In order to protect battery or other electric parts, don, t put the scooter into
- water with height more than 4cm or spraied by water
- 13.In orderto avoid unnessary hurt, please don't use it when the weather is bad, such as heavy rainning, and heavy snowing etc.
- —The electric scooter use as transporter for short distance way or for leisure pleasure
- -Model No Z3T, Motor 350W, Lithium battery 10 AH, 10 inch
- —Non zero start, switch on the power and touch the accelerator, one foot stand on the panel, use another foot to push the scooter forward at speed not less than 3km/h

- —The scooter with front lamp and rear lamp, once switch on the power, the rear lamp shall be light automatically. And for front lamp, it need to controlled by the button, click the power button single time, to open the lamp, and then click another single time to close the lamp.
- —With disc brake and electric brake, Fixed-speed cruise, 3 different classed speed level.
- —Please put the scooter on a safety place if not use it, and open the foot brace
- -Any load attached to the handlebar will affect the stability of the vehicle.
- —The scooter can be used only for one person.
- —Any accessories and any additional items which are not approved by the manufacturer shall not be used.
- -the minimum height of the user, isl.4m
- —the maximum age 60 and minimum age 13 of the user as appropriate.
- -The mandatory marking CE
- —The user should check the limits of use in accordance with the local regulations (e.g. use in pedestrian areas, on-road);
- Necessary preparation for using the product: check the steering system to ensure that it is correctly adjusted.
- all condition elements (such as the folding system) shall be correctly tightened and not broken, and that the brakes
- and wheels are in good condition;
- —Warning: Always wear shoes!
- Do not ride the venicle after dark or in poor visibility conditions! Do not touch the brake disc after braking!

- —Avoid high traffic areas or overcrowded areas;.
- -Cross the protected passages while walking.
- —In all cases, take care of yourself and others.
- -Do not divert the use of the vehicle
- —This vehicle is not intended for acrobatic use.
- —Regularly check the tightening of the various bolted elements, in particular the wheel axles, the folding system, the steering system and the brake shaft.
- —Eliminate any sharp edges caused by use.
- —Do not modify or transform the vehicle, including the steering tube and sleeve, stem, folding mechanism and rear brake.
- —Requirement to switch off the vehicle during charging, orinto a certain non-operational mode;
- —Requirement to switch off the vehicle during charging, orinto a certain non-operational mode;

Traffic in the city has many obstacles to cross such as curb sorsteps. It is recommended to avoid obstacle jumps. It is important to anticipate and adapt your trajectory and speed to those of apedestrian before crossing these obstacles. It is also recommended to get out of the vehicle when these obstacles become dangerous due to their shape, height or slippage.

PRODUCTS

In any case, anticipate your trajectory and your speed while respecting
The code of the road, the code of the side walk and the most vulnerable;
Caution, the brake may become hot in use. Do not touch after use
Take some time to learn the basics of the practice to avoid any serious
serious accideng that can take place in the first month; Get closer to
your seller so he Can refer you to an appropriate training organization;



UNFOLDING STATE

FOLDING STATE

FOLDING STEPS

01 Rotate 90 degrees clockwise



02 Pull the sleeve upward



03 push the stemdownward to fold and fix it with the hook



04 folding finished



UNFOLDING STEPS

01 pull the sieeve outward



02 push the stem upward




03 move the sleeve downward



04 counter clock wise rotate 90degrees



HEAD MOUNTING




Take out the head part




Pull out the wires, and connect two wires following the instructions

HEAD MOUNTING



Insert the head part into the serm,and fix it with two screws



Ensure the screw being tighted,installing is finished

BASIC OPERATION

- **A** Power switch
- **B** Gear setting
- © Speed controler

- (D) Brake controler
- **(E) LED lamp**
- (F) LED light switch



OPERATION INSTRUCTION

Power switch

Press it shorttime 1 second to open it and press about 3 second to close it

Gear setting

Double times click it to change gear position from 1-3 different speed lever

Speeding controler

Press right accelerator to control the speed at l-25km/h

Brake controler

Press left brake to stop the scooter, more heavy pressing, brake effect shall be faster to stop it

LED lamp

Single-click to switch on or switch off the lamp

Emergency brake

When you meet with emergency, please press the rear fender to let scooter stop fast. Meanwhile* the rear wheel scuffed also fast Jf so, it has nothing to do with manufacturer.

SWITCH MODE FORSTARTUPAND CLOSEOFF

Press the power switch 1 second to open or close it, hit the switch button By: dual time for switching gear freely



Hit lamp button, command character shall be showed on the display



Traval display



Press the power switch 3 seconds to switch off the scooter



RIDING OPERATION

01

Prepare to start

- 1.Choose one place suitable for riding
- 2.Unfold the scooter according to the manuals

03

Parking

Pressing left brake to control the speed coming down, the more the angle to press, the faster the time to stop the scooter.

Use rear brake to press the fender by foot once you meet with emergency, meanwhile, control the scooter speed come down by electric brake for front wheel and disk brake for rear wheel

02

Start to ride

- .Switch on the power
- 2.One food on the pedal, and another one foot on the ground
- 3. Press the acceleration, meanwhile move the scooter forward at uniform speed by the foot, and then put both feet stand on the pedal.

BATTERY AND CHARGER

each scooter LI with a special lithium battery and charger, each product and accessory has one special code, please don't use other brand charger to charge it, neanwhile, our charger are not possible for other brand scooters, otherwise, we are not responsible for it.

01

Battery

Please charge full battery for first time before using it. The battery can be charged at any time, and there is no any damage to charge frequently. Meanwhile, please don't forget to charge it per 3 months if you don't use it for a long term.

02

Charger

The charger with auto-protected function, it shall be power off when the battery is 100% full. Charging time is 3-4hours normally. It is not in the range of quality warrant time if the chargerdamaged because of un-normal using

03

Charging instruction

- .Open the rubberand insert the plug into the hole
- 2.Insert another one plug ofthe charger into the electric outlet
- Whenthe indicator lamp is red, it shows the batter being charging,
 when the lamp is green, the battery finished charging

MAINTENANCE

Lubrication

Folded place need to be put few Lubricating oil per 6 months, inspect the scooter per 3 months, to ensure all screws fit well. If the screws are loosing, please screw home tightly.

Battery

Lithium battery can be charged 500 times at least, it can be used 1000 times normally, we suggest you to charge fully and use out of the battery every time, otherwise, the life of the battery shall be reduced.

Parking & daily using

Don't put the scooter underthe sunshining or other damp place for a long term, keep the scooter clean usually.

The vehicle is equipped with a kickstand on the left side (in the forward direction), it is easily to operate for parking. The parking device and the vehicle should be folded back when the vehicle not being used for a long term.

SOLUTION WAYS FOR GENERAL QUESTIONS

Inspecting list

Please try to solve it refer to following ways when you meet with the problem:

01

Displayer is black

Reason: exposure time underthe sun is

iolving ways: put the scooter in dark place for a while and recover it

The digits showed on the displayer is notin accordance with the actual information

Reason: parameter setting is wrong or lost Solving way: reset it according to the manua

03

Digits is indistinct

Reason: bad contact for the battery or weak battery

Solving way: switch offthe power and then restart it, if still same, please contact with manufacturer or distributor

04

Please check following steps finished or not if the product can network

a.Powerisonorno

b.Check the battery has electricity or not
 c.Left brake& rear brake on original
 position or not

con nected correctly or not, if connected correctly and still can network, please contact with distributor or manufacturer.

PRODUCT PARAMETER				
Item No	Z3T			
G.W/N.W	25/20KG			
Max speed	30Km/h			
Per charger	35 Km			
Lituium battrey	36V/10Ah			
Max load	200KG			
Max climbing	30°			
Water Proof				
Motor	36V/500W*l			
Tire	10'VACUUMTIRE			
Brake	BACK/RARE DISC BRAKE			
Led Display	Speed, Gear, Power Display			
Shock-Absorption				
Charger Time	6-7 Hour			
Carton Size	1205*235*522 mm			
Folding size	1190*575*535 mm			
Unfolding Size	1190*575*1150 mm			

QUALITY GUARANTEE

If accessories happened with following problems under normal using and during the warranty period, please contact with us or our distributor, we shall provide after-sale service foryou.

Spareparts	Quality problem	guarantee period	service content
motor	Under normal use broken	1 year	Free maintenence
battery	Can't charge and discharge under normal using	1 year	Free maintenence
body	Under normal use broken	1 year	Free maintenence

Please use itin correct ways, otherwise, the accessories shall be easily broke, we are not resposible for it. If the products and accessories can not work or damaged during warranty period and because of following reasons, we are not responsible for it.

- $1.\mbox{No}$ normal maintenance according to the instructions
- 2. Change other factory 5 s or brand's battery and charger without authorization
- 3. Use scooter for other purpose, such as high risk performance $\,$
- 4.Damage caused by disassemble or reinstall
- 5.Improper using, traffic accident or other damage caused by collide
- 6.The label is damaged, product code for scooter body is not correspond with the accessories
- 7. Damage caused by riddingon unsuitable road
- 8.Importer no licence

All other improper damage

Warranty

Please properly keep the warranty card and purchase invoices as after-sales credential. Airwheel will provide the following after-sales services providing not damaged by the user.

After-sales Service

- 1. The electric scooter will be guaranteed for one year, except the batteries and consumable items
- 2. We can maintain the battery and charger for half year; since tires belong to consumable material one month is provided for maintenance. Following circumstances are not included in the free repairing scope.
- 1. Malfunction is cause by users who are not in accordance with the provisions of the operation instruction handbook to use, maintain and adjust,
- 2. Damage and failure is caused by users' self-refit, self-repair and without compliance with application regulations.
- 3. Failure is caused by user improper safekeeping or accidents.
- 4. There is no warranty card and invoice or discrepancy between the vehicle and the card.
- 5. The appearance damage after using does not belong to the warranty scope.
- 6.Self-demolition piece used is excluded from Operation Manual.
- 7. Damage is caused by long time riding in the rain and soaking in water.



Doc No · V25

Record of extended warranty

Part Name		start date of extended warranty		Extended period	
Part Name		start date of extended warranty		Extended period	
Part Name		start date of extended warranty		Extended period	
Please refer to the mare rever efficial website for latest info undate					

Part Name		start date of extended warranty		Extended period	
U ser Info)	Please r	efer to the mars rover o	offcial website	for latest info updat
Name :		Tel:	Email		
Address :					
Product inf	o				
Model		Servi	ce center:		
Repair date: _					
Repair details:					
•					
Cause of maitunc	tion				
SN :					Seal of the Service Center
Signature of the	repairman :				edi of the Service Certier

Aftersales info

Please vit our ofcial website for the adres of the service center and other related info.

Research: Ainwheel Europe S.A.

Supervisor: Airwheel Holding Limited

Manufacture: Changzhou Aiwheel Technology Co.,Ltd.

Address 5th Foor East Wing Buling No.1. High-Tech Park Kewu Road. Xinbei

District, Changzhou, iangsu, China



data is only for reference. be subject to the real object.